



## Instructions for use of the oil burners

Follow these tips to ensure that you get many years of use from your oil burner.

1. Remove the oil holder from the lamp before filling it with paraffin or lamp oil.
2. Remove the lamp chimney and carefully unscrew the burner (be careful not to use the stem of the burner as a lever when doing this).
3. Fill the oil holder approximately 3/4 full with paraffin or a colourless lamp oil.
4. Screw the burner back on to the oil holder again. Leave the wick to become fully saturated for approximately 30 minutes.
5. Turn up the wick until it emerges just above the wick holder.
6. If necessary trim the wick level using a pair of scissors or a Sharp knife.
7. After lighting the wick replace the lamp chimney and keep the flame low until the cold glass has had time to warm so as to prevent the glass from cracking.
8. Now adjust the flame such that there is no smoke. When the lamp is first used this adjustment will need to be repeated a number of times as the wick stretches.
9. To extinguish the burner turn the wick down until the flame goes out.
10. Allow the lamp chimney to cool before relighting the lamp.
11. To prevent the swollen wick damaging the turning mechanism of (normal) burners it is recommended that the wick be replaced on an annual basis.

**Make sure that both the oil lamp and the bottle of lamp oil are kept out of the reach of children.**

